

Self-operated Pressure Regulators

SAMSON

Differential Pressure Regulators

Type 45-1 and Type 45-2 · Installation in the high-pressure pipe

Type 45-3 and Type 45-4 · Installation in the low-pressure pipe



Type 45-1



Type 45-2

Mounting and Operating Instructions

EB 3124 EN

Edition November 2016

CE

Note on these mounting and operating instructions

These mounting and operating instructions assist you in mounting and operating the device safely. The instructions are binding for handling SAMSON devices.

- For the safe and proper use of these instructions, read them carefully and keep them for later reference.
- If you have any questions about these instructions, contact SAMSON's After-sales Service Department (aftersaleservice@samson.de).



The mounting and operating instructions for the devices are included in the scope of delivery. The latest documentation is available on our website (www.samson.de) > Product documentation. You can enter the document number or type number in the [Find:] field to look for a document.



WARNING!

Damage to health relating to REACH Regulation.

If a SAMSON device contains a substance which is listed as being a substance of very high concern on the candidate list of the REACH Regulation, this circumstance is indicated on the SAMSON delivery note.

*Information on safe use of the part affected,
see ► <http://www.samson.de/reach-en.html>*

Definition of signal words



DANGER!

Hazardous situations which, if not avoided, will result in death or serious injury



NOTICE

Property damage message or malfunction



WARNING!

Hazardous situations which, if not avoided, could result in death or serious injury



Note:

Additional information



Tip:

Recommended action

| | | |
|-----------|---|-----------|
| 1 | General safety instructions..... | 4 |
| 2 | Process medium and scope of application..... | 5 |
| 2.1 | Transportation and storage | 5 |
| 3 | Design and principle of operation | 5 |
| 4 | Installation | 8 |
| 4.1 | Mounting position | 8 |
| 4.2 | Control line | 8 |
| 4.3 | Strainer (filter)..... | 8 |
| 4.4 | Shut-off valves | 8 |
| 4.5 | Pressure gauges | 9 |
| 5 | Operation | 9 |
| 5.1 | Start-up..... | 9 |
| 5.2 | Adjusting the set point | 9 |
| 5.3 | Decommissioning | 10 |
| 6 | Maintenance · Troubleshooting | 10 |
| 6.1 | Cleaning or replacing the plug..... | 12 |
| 6.2 | Replacing the operating diaphragm | 12 |
| 7 | Nameplate..... | 14 |
| 8 | After-sales service | 15 |
| 9 | Dimensions | 16 |
| 10 | Technical data | 18 |



1 General safety instructions

- The device must be mounted, started up, or serviced by fully trained and qualified personnel only; the accepted industry codes and practices are to be observed. Make sure employees or third persons are not exposed to any danger.
- All safety instructions and warnings given in these mounting and operating instructions, particularly those concerning installation, start-up, and maintenance, must be strictly observed.
- According to these mounting and operating instructions, trained personnel refers to individuals who are able to judge the work they are assigned to and recognize possible dangers due to their specialized training, their knowledge and experience as well as their knowledge of the applicable standards.
- The devices comply with the requirements of the European Pressure Equipment Directive 2014/68/EU. The declaration of conformity issued for a regulator bearing the CE marking includes information on the applied conformity assessment procedure. This declaration of conformity can be provided on request.
- To ensure appropriate use, only use the device in applications where the operating pressure and temperatures do not exceed the specifications used for sizing the device at the ordering stage.
- The manufacturer does not assume any responsibility for damage caused by external forces or any other external factors.
- Any hazards that could be caused in the regulator by the process medium, operating pressure or by moving parts are to be prevented by taking appropriate precautions.
- Proper transport, storage, installation, operation, and maintenance are assumed.

Note: Non-electric control valve versions whose bodies are not lined with an insulating material coating do not have their own potential ignition source according to the risk assessment stipulated in EN 13463-1: 2009, section 5.2, even in the rare incident of an operating fault. Therefore, such valve versions do not fall within the scope of Directive 2014/34/EU.

2 Process medium and scope of application

Differential pressure regulators for district heating systems, extended piping systems, and industrial applications

Differential pressure set points (Δp) from **0.1** to **10 bar** · Valves in **DN 15** to **50** · Nominal pressure **PN 16** and **25** · Suitable for liquids ¹⁾ up to **150 °C** as well as nitrogen and air up to **150 °C** ²⁾

- ¹⁾ The materials in the regulator are also resistant to high concentrations of glycol. Nevertheless, glycol may decompose gradually during use. During which, corrosive substances, e.g. acids may form under certain circumstances. We cannot prevent this reaction. Therefore, plant operators must prevent it by using suitable inhibitors.
- ²⁾ Diaphragm and seals made of FPM (FKM). Only version in PN 25.

2.1 Transportation and storage

The devices must be carefully handled, transported, and stored. Protect the regulator against adverse influences, such as dirt, moisture or frost, during storage and transportation.

3 Design and principle of operation

See Fig. 3 on page 7.

The differential pressure regulators basically consist of the valve with balanced plug as well as a closing actuator with an operating diaphragm.


In Type 45-1 and Type 45-3, the set point spring (8) installed into the valve determines the set point. Whereas, in Type 45-2 and Type 45-4, the set point can be adjusted by the set point springs (8) in the actuator.

The differential pressure regulators are designed to maintain a constant differential pressure between the high-pressure and low-pressure lines to an adjustable set point.


The valve closes when the differential pressure exceeds the adjusted set point.

Types 45-1 and 45-2 · Installation in the flow pipe

The medium flows through the valve in the direction indicated by the arrow. The pressure in the valve outlet (high pressure) is transferred to the high-pressure chamber of the actuator over the attached control line (11) and the low pressure from the return flow pipe is transferred to the low-pressure chamber of the actuator over a control line (12) to be installed on site.



borehole (13) and the high pressure from the flow pipe is transferred to the high-pressure chamber of the actuator over a control line (11) to be installed on site.



The differential pressure creates a positioning force at the operating diaphragm which moves the valve plug depending on the force of the set point spring(s) (8/10).

Types 45-3 and 45-4 · Installation in the return flow pipe


The pressure upstream of the valve (low pressure) is transferred to the low-pressure chamber of the actuator through the

Table 1: Tightening torques · See Fig. 3

| Tightening torques | | |
|--------------------|------------------------|-----|
| Position | DN | Nm |
| Plug (3) | 15 to 25 | 70 |
| | 32 to 50 | 110 |
| Screw (14) | 15 to 32 | 8 |
| | 40 and 50 | 18 |
| Control line (11) | 15 to 50 | 22 |
| | 15 to 25 ¹⁾ | 10 |

¹⁾ For PN 16


Type 45-2 (45-4)




Type 45-4 (45-2) · DN 15 to 32

Set point range 0.1 to 0.5 bar and 0.1 to 1 bar

Type 45-2 only



Type 45-1 (45-3)



- 1 Valve body
- 2 Seat
- 3 Plug
- 4 Diaphragm plate
- 5 Nut
- 6 Operating diaphragm
- 7 Diaphragm case
- 8 Set point spring (ready adjusted set point)
- 8.1 Valve spring
- 9 Set point adjuster
- 10 Set point springs (for set point adjustment)
- 11 Control line attached (Types 45-1 and 45-2)
External control line (Types 45-3 and 45-4)
- 12 External control line (Types 45-1 and 45-2)
- 13 Borehole in the body (Types 45-3 and 45-4)
- 14 Screws
- 15 Spring plate
- 16 Bottom section of the body
- 17 Support
- 18 Spindle
- 19 Set point adjuster (manual adjuster)
- 20 Internal excess pressure limiter (overload protection, Types 45-3 and 45-4 only)

Fig. 3: Functional diagrams

4 Installation

See Fig. 3 on page 7.

4.1 Mounting position

Install the differential pressure regulator in horizontal pipelines with the actuator suspended downward (regulators in DN 15 to 25 can also be installed in vertical pipelines).

For medium temperatures above 80 °C, installation with the diaphragm actuator on top is **not** permitted.

- ➔ Make sure the regulator is installed free of stress.
- ➔ The flow of direction must correspond with the direction indicated by the arrow on the valve body.
- ➔ Install a strainer (e.g. SAMSON Type 1 NI) upstream of the regulator to prevent any sealing parts, weld spatter, and other impurities carried along by the process medium impairing the proper functioning of the valve, above all the tight shut-off.

NOTICE

Possible malfunction and damage due to adverse effects of weather conditions (temperature, humidity). Do not install the regulator outdoors or in rooms prone to frost. If such a location cannot be avoided, protect the regulator against freezing up if the process medium flowing through the valve can freeze up. Either heat

the regulator or remove it from the plant and completely drain the residual medium.

4.2 Control line

A control line with 6 mm pipe diameter must be adapted and mounted on site. Make sure that the control line is free of dirt.

Refer to the installation schematics (Fig. 1 and Fig. 2) for routing the control line.

4.3 Strainer (filter)

A strainer installed upstream in the flow pipe holds back any dirt or other foreign particles carried along by the medium. For example, the SAMSON Type 1 N/1 NI Strainer is suitable (▶ T 1010).

- ➔ Install the strainer upstream of the regulator.
- ➔ The direction of flow must correspond to the arrow on the body.
- ➔ The filter element must be installed to hang downwards or sideways for applications with steam. Remember to leave enough space to remove the filter element.

4.4 Shut-off valves

Install a hand-operated shut-off valve both upstream of the strainer and downstream of the regulator. This allows the plant to be shut down for cleaning and maintenance, and when the plant is not used for longer periods of time.

4.5 Pressure gauges

Install a pressure gauge both upstream and downstream of the regulator to monitor the pressures prevailing in the flow pipe and return flow pipe at the point of tapping of the control line.

5 Operation

5.1 Start-up

See Fig. 3 on page 7.

- Open all the valves on the consumer side.
- Slowly open the shut-off valves.



NOTICE

The pressure at the actuator must not exceed the nominal pressure by 1.5 times nor the maximum permissible differential pressure Δp across the valve on testing the pressure of the plant when the regulator is already installed.

5.2 Adjusting the set point

Adjust the required differential pressure of Type 45-2 and Type 45-4 by tensioning the springs at the set point adjuster (9).

- Turn clockwise (↻): to increase the differential pressure.
- Turn counterclockwise (↺): to reduce the differential pressure.

For nominal sizes DN 15 to 32 with set point ranges from 0.1 to 0.5 bar and 0.1 to 1 bar, the set point springs are installed in the bottom section of the valve body. In this case, the set point can be directly adjusted at the manual adjuster (19) according to the scale.




Fig. 4: Set point adjusted according to the value on the scale

One turn of the manual adjuster will change the differential pressure by 0.033 bar in the range from 0.1 to 1 bar and by 0.02 bar in the range from 0.1 to 0.5 bar.



Note:

Do not adjust the set point to a value on the scale lower than 1.

Under unfavorable conditions, the set point cannot be adjusted anymore as a result.

To allow the set point to be adjusted again, proceed as follows:

- Relieve the regulator of pressure.
- Turn the manual adjuster counterclockwise ⤴ as far as it will go.
- Turn the manual adjuster back clockwise ⤵ at least past the value 1 to 2 on the scale.

The set point can be adjusted again.

5.3 Decommissioning

Close the shut-off valves starting from the flow pipe (high-pressure line).

6 Maintenance · Troubleshooting

The regulators do not require any maintenance. Nevertheless, they are subject to natural wear, particularly at the seat, plug, and operating diaphragm.

Depending on the operating conditions, check the regulator at regular intervals to avoid possible malfunctions.



WARNING!

Before performing any work on the regulator, make sure the relevant plant section has been depressurized and, depending on the process medium, drained. We recommend removing the valve from the pipeline.

When used at high temperatures, allow the plant section to cool down to ambient temperature. Disconnect or shut off the control line to prevent the risk posed by moving regulator parts. As valves are not free of cavities, remember that residual process medium might still be contained in the valve.

Details on faults and how to remedy them can be found in Table 2.

To replace the plug and operating diaphragm, proceed as described in section 6.1 and section 6.2.

Table 2: Troubleshooting

| Malfunction | Possible reasons | Recommended action |
|---|---|--|
| Differential pressure exceeds adjusted set point. | Leak between seat and plug | Remove valve from the pipeline and clean seat and plug. Replace the plug, if possible. If this is not possible, return regulator to SAMSON for repair. |
| | Defective operating diaphragm | Replace diaphragm or return regulator to SAMSON for repair. |
| | Control line blocked | Remove control line and clean it. |
| | Valve too large for control task | Recalculate K_{VS} and contact SAMSON for further action. |
| Differential pressure set point not reached | Valve too small for control task | Recalculate K_{VS} and contact SAMSON for further action. |
| | Safety device, e.g. pressure limiter, has been triggered. | Check plant. Unlock safety device. |
| | Plant differential pressure Δp too low | Compare differential pressure in the plant with the plant's drag. |
| | Strainer blocked | Drain and clean filter of the strainer. |
| | Incorrectly installed valve (direction of flow). | Install the valve in such a way that the flow of direction corresponds with the direction indicated by the arrow on the valve body. |
| Control loop hunts. | Valve too large for control task | Recalculate K_{VS} and contact SAMSON. |

If faults cannot be remedied following the recommended action in the table, contact SAMSON (see section 8).

6.1 Cleaning or replacing the plug

See Fig. 3 on page 7.

1. Unscrew the external control line and remove the device from the pipeline.
2. For Type 45-2 and Type 45-4, completely relieve the tension from the springs by turning the set point adjuster (9) or manual adjuster (19) counterclockwise. Unscrew the control line (11) on Type 45-1 and Type 45-2.
3. Unscrew the screws (14) and remove the entire actuator.
Pull the valve spring (8.1), if installed, out of the valve body.
4. For valve sizes DN 15 to 25, unscrew and pull out the guide nipple of the plug section (3) using a socket wrench (SAMSON order no. 1280-3001).
5. For valve sizes DN 32 to 50, unscrew the stopper first and pull out the plug section.
6. Clean the seat and plug section thoroughly. The entire plug section must be renewed if the plug is damaged.
7. Check the control lines and the borehole in the body (Type 45-3 and Type 45-4) for blockage.

To reassemble, proceed in reverse order. Observe tightening torques specified in Table 1.

6.2 Replacing the operating diaphragm

See Fig. 3 on page 7.

Types 45-1, 45-2, and 45-3

1. Unscrew the external control line and remove the device from the pipeline.
2. Unscrew the control line (11) from Type 45-1 and Type 45-3.
3. Unscrew the screws (14). Remove the bottom diaphragm case (7) together with the diaphragm (6) and diaphragm plate (4) from the body.
Pull the valve spring (8.1), if installed, out of the valve body.
4. Unscrew the nut (5) and lift off the diaphragm plate. Replace the diaphragm.

To reassemble, proceed in reverse order. Observe tightening torques specified in Table 1.

Types 45-2 and 45-4: version without manual adjuster

1. Unscrew the external control line and remove the device from the pipeline.
2. Completely relieve the tension from the spring(s) by turning the set point adjuster (9) counterclockwise \curvearrowright .
3. Unscrew the control line (11) from Type 45-2.
4. Unscrew the screws (14). Remove the bottom diaphragm case together with the actuator parts as well as the diaphragm and diaphragm plate.

5. Unscrew the nut (5) and lift off the diaphragm plate. Replace the diaphragm.

To reassemble, proceed in reverse order. Observe tightening torques specified in Table 1.

Types 45-2 and 45-4: version with manual adjuster


1. Unscrew the control line (11) from Type 45-2.
2. Completely relieve the tension from the springs (10) by turning the manual adjuster (19) counterclockwise until a clicking noise is heard.
3. Unscrew the screws (14). Take off the bottom section (16) of the valve body. Pull the valve spring (8.1) out of the valve body.
4. Unscrew the complete assembly unit (consisting of diaphragm together the diaphragm plates, spring, and support) from the spindle (18) by turning the unit counterclockwise \curvearrowright . Pull it out the bottom section of the valve body.
5. After changing the diaphragm, push the assembly unit into the bottom section over the spindle and turn it clockwise \curvearrowleft one turn to fasten it onto the spindle.
6. Lift the diaphragm plate to check whether the thread of the spring plate (15) has engaged. If not, turn it once more.
7. Push the valve spring (8.1) into the valve body.

Align the bottom section of the body with the control line connections and fasten it onto the valve body and evenly tighten

the screws (14). Observe the tightening torque specified in Table 1.

8. Screw the control line onto Type 45-2. Observe the tightening torque specified in Table 1.
9. Install the regulator into the pipeline and mount the external control line.
10. Adjust the differential pressure set point according to section 5.2 on page 9.

7 Nameplate



Note:

Conversion from chromate coating to iridescent passivation

We at SAMSON are converting the surface treatment of passivated steel parts in our production. As a result, you may receive a device assembled from parts that have been subjected to different surface treatment methods. This means that the surfaces of some parts show different reflections. Parts can have an iridescent yellow or silver color. This has no effect on corrosion protection.

For further information go to ► www.samson.de/chrome-en.html

8 After-sales service

Contact SAMSON's After-sales Service department for support concerning maintenance or repair work or when malfunctions or defects arise.

E-mail

You can reach the After-sales Service Department at aftersaleservice@samson.


Addresses of SAMSON AG and its subsidiaries

The addresses of SAMSON AG, its subsidiaries, representatives, and service facilities worldwide can be found on the SAMSON website (► www.samson.de) in all SAMSON product catalogs or on the back of these Mounting and Operating Instructions.

To assist diagnosis and in case of an unclear mounting situation, specify the following details (so far as possible):

- Type and nominal size of the valve (see Nameplate)
- Model number and configuration ID (Var.-ID). See Nameplate.
- Upstream pressure p_1 and downstream pressure p_2
- Temperature and process medium
- Min. and max. flow rate
- Is a strainer installed?
- Installation drawing showing the exact location of the regulator and all the additionally installed components (shut-off valves, pressure gauge, etc.)

9 Dimensions



Dimension tables

Table 3: Dimensions in mm · Standard version (with welding ends)

| Nominal size DN | 15 | 20 | 25 | 32 ¹⁾ | 40 ¹⁾ | 50 ¹⁾ |
|-----------------|------|------|------|------------------|------------------|------------------|
| Pipe Ø d | 21.3 | 26.8 | 32.7 | 42 | 48 | 60 |
| Connection R | G ¾ | G 1 | G 1¼ | G 1¾ | G 2 | G 2½ |
| AF | 30 | 36 | 46 | 59 | 65 | 82 |
| Length L | 65 | 70 | 75 | 100 | 110 | 130 |
| H | 32 | | | 45 | | |
| H1 | 230 | | | 250 | 380 | |
| H2 | 160 | | | 180 | - | |
| H3 | 85 | | | 105 | 140 | |
| Ø D | 116 | | | | 160 | |

1) Additional version: valve with flanged body

**Note:**

The dimensions and weights of valves with flanged bodies (DN 32, 40, and 50) are the same as valves with screwed-on flanges.

Table 4: Dimensions in mm and weights in kg · Including connecting parts

| Nominal size DN | 15 | 20 | 25 | 32 | 40 | 50 | |
|--|--------------------|------------|------------|------------|------------|-------------|--------------|
| With welding ends | | | | | | | |
| Length L1 | 210 | 234 | 244 | 268 | 294 | 330 | |
| Weight, approx. kg | 45-2/-4 45-1/-3 | 2.0 1.5 | 2.1 1.6 | 2.2 1.8 | 8.5 4.8 | 9 5.3 | 9.5 6.0 |
| With threaded ends | | | | | | | |
| Length L2 | 129 | 144 | 159 | 192 | 206 | 228 | |
| Male thread A | G ½ | G ¾ | G 1 | G 1¼ | G 1½ | G 2 | |
| Weight, approx. kg | 45-2/-4 45-1/-3 | 2.0 1.5 | 2.1 1.6 | 2.2 1.8 | 8.5 4.8 | 9.0 5.3 | 9.5 5.8 |
| With flanges^{1) 2)} or with flanged body (DN 32 to 50) | | | | | | | |
| Length L3 | 130 | 150 | 160 | 180 | 200 | 230 | |
| Weight, approx. kg | 45-2/-4 45-1/-3 | 3.4 2.9 | 4.1 3.6 | 4.7 4.3 | 11.7 8 | 13.0 9.3 | 14.5 10.8 |

1) PN 16/25

2) Flanges are already mounted on valves in DN 40 and 50

10 Technical data

| Nominal size | | DN 15 | DN 20 | DN 25 | DN 32 ¹⁾ | DN 40 ¹⁾ | DN 50 ¹⁾ |
|--|---------------------|---|-------|-------|---------------------|---------------------|---------------------|
| K _{VS} coefficient | Standard | 2.5 | 6.3 | 8 | 12.5 | 16 | 20 |
| | Special version | 0.4 · 1.0 4.0 | - | | | | |
| | Flanged body | - | | | 12.5 | 20 | 25 |
| x _{FZ} value | Standard | 0.6 | 0.55 | | | 0.45 | |
| | Flanged body | - | | | 0.45 | | 0.4 |
| Nominal pressure | Types 45-2 and 45-4 | PN 25 | | | | | |
| | Types 45-1 and 45-3 | PN 25 and 16 | | | PN 25 | | |
| Max. permissible differential pressure Δp across the valve | | 20 bar/10 bar ²⁾ | | | | 16 bar | |
| Max. permissible valve temperature | | Liquids: 150 °C/130 °C ²⁾ · Air and nitrogen: 150 °C ³⁾ | | | | | |
| Pressure above adjusted set point at which internal excess pressure limiter responds (Types 45-3 and 45-4) | | 0.5 bar | | | | | |
| Compliance | |  | | | | | |
| Differential pressure set point ranges | | | | | | | |
| Types 45-1 and 45-3, fixed set point | | 0.1 · 0.2 · 0.3 · 0.4 or 0.5 bar | | | | | |
| Types 45-2 and 45-4, continuously adjustable | | 0.1 to 1 bar · 0.1 to 0.5 bar | | | | 0.2 to 1 bar | |
| | | 0.5 to 2 bar · 1 to 4 bar | | | | | |

¹⁾ Additional version: valve with flanged body made of spheroidal graphite iron (EN-GJS-400-18-LT)

²⁾ For PN 16 version

³⁾ Diaphragm and seals made of FPM (FKM) · PN 25 version only



SAMSON AG · MESS- UND REGELTECHNIK
Weismüllerstraße 3 · 60314 Frankfurt am Main, Germany
Phone: +49 69 4009-0 · Fax: +49 69 4009-1507
samson@samson.de · www.samson.de

EB 3124 EN

2017-02-24 · English