



Gerät / Device			Anzeige- und Bedienkomponente (ABK) / Indicating and operating modules							
Model Index	Firmware K <sup>1</sup> / R <sup>2</sup>	Device Rev	PA Profile Rev	TROVIS-VIEW	Siemens PDM <sup>3</sup>	DTM (FDT 1.2)				
00	K 1.00 R 1.43	1	3.01	≥ 3.22	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
00	K 1.01 R 1.43	1	3.01	≥ 3.22	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
00	K 1.10 R 1.44	1	3.01	≥ 3.22	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
00	K 1.11 R 1.45	2	3.01	≥ 3.40	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
00	K 1.12 R 1.45	2	3.01	≥ 3.40	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
01	K1.13 R1.46	2	3.01	≥ 3.40	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
01	K1.15 R1.46	2	3.01	≥ 3.40	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
01	K1.16 R1.46	2	3.01	≥ 3.40	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				
01	K1.17 R1.46	2	3.01	≥ 3.40	≥ 5.1 ≥ 6.0 <sup>6</sup>	≥ 1.3.0				

<sup>1</sup> Firmware Kommunikation

<sup>2</sup> Firmware Regelung

<sup>3</sup> Gerät wird in PDM per ‚device install‘ / ‚Gerätekatalog verwalten‘ nachträglich installiert (verfügbar über <http://www.samson.de>)

<sup>6</sup> mit Enhanced EDD

<sup>20</sup> in Kürze verfügbar