



Elektropneumatic Positioner Type 3730-5

Device		Indicating and operating modules								
Model Index	Firmware K <sup>1</sup> / R <sup>2</sup>	FF Device Rev	TROVIS VIEW	DTM (FDT 1.2)	Field Communicator 375/475	Emerson DeltaV	Yokogawa Centum	Honeywell Experion PKS	ABB Industrial IT	Foxboro I/A Series
00	K 1.00 – 1.22 R 1.00 – 1.41	1	≥ 3.20	≥1.0.0	✓	≥ 6.1 <sup>14,15</sup>	✓ <sup>14,15</sup>	✓ <sup>14</sup>	✓ <sup>14,15</sup>	✓ <sup>14</sup>
01	K 1.23 – 1.25 R 1.44 – 1.46	1	≥ 3.20	≥1.0.0	✓	≥ 6.1 <sup>14,15</sup>	✓ <sup>14,15</sup>	✓ <sup>14</sup>	✓ <sup>14,15</sup>	✓ <sup>14</sup>
01	K 2.00 – 2.02 R 1.52	2	≥ 3.20	≥1.0.0	✓	≥ 8.4 <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>
01	K 2.03 – R 1.54	2	≥ 3.20	≥1.0.0	✓	≥ 8.4 <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>
01	K 2.04 – R 1.55	2	≥ 4.21	≥1.0.0	✓	≥ 8.4 <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>
01	K 2.05 – R 1.56	2	≥ 4.21	≥1.0.0	✓	≥ 8.4 <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>
01	K 2.06 – R 1.56	2	≥ 4.21	≥1.0.0	✓	≥ 8.4 <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>
01	K 2.07 – R 1.57	2	≥ 4.21	≥1.0.0	✓	≥ 8.4 <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>
01	K 3.00 – 3.02 R1.61 – 1.63	3	≥ v4.52	≥1.0.0	✓	≥ 12.x <sup>6,14</sup>	✓ <sup>6,14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>	✓ <sup>14</sup>

1 Communication firmware

2 Control firmware

6 With enhanced DD (EDD)

14 Device Description available at <http://www.samson.de/>

15 Basic Device